



Installations, Tips and Tricks

(Leaflet E004 – Updated 28.08.2008)

Installation procedure for Upper Fork Clamp- Ducati S4/ST2/ST4

The screws (M8) must be tightened with a torque of 20 to 22 Nm! This value must be applied to avoid faulty gripping.

The screws for fixing the instruments must be safed with Loctite.

Please verify the correct torque after 300 Miles or two month latest.

Have fun and a successful installation, yours MPL-Team!!!