



Installations, Tips and Tricks

(Leaflet E005 – Updated 28.08.2008)

Installation procedure for Upper Fork- Ducati 748-998

The screws (M8) must be tightened with a torque of 20 to 22 Nm! Please pay attention to this value to avoid faulty gripping.

Please verify the correct torque after 300 Miles or two month latest.

Have fun and a successful installation, yours MPL-Team!!!